

Right-click on the “Solution1” folder and select “Solution Settings...”

Then in the General tab, go to config_rtl and select the “all” option for reset as shown below

